

Features

- 1. Special optical lens is used
- 2. The Aluminum PCB back uses heat dissipation tape
- 3. Using external controllers can achieve rich color conversion
- 4. Multiple specifications available and customizable

Application

Suitable for advertising lightbox and signage lighting project etc.

Installation

Fix by adhesive tape or screws



Specification

Model No.	Light Color	Color Temperature/ Wavelength(K/nm)	Beam Angle	Typical Luminous Flux value(lm/pcs)	Ra	Efficacy (lm/W)	Voltage (V DC)	Power (W/pcs)
VSL-V-RGBW-0407-24	W	6500		243	70+	86	24	3
	R	615-625	10*20°	138		45		3
	G	515-530		247		83		3
	В	450-460		38		14		3
	RGB	100000		409		46		9
	RGBW	100000		630		53		12

Other Parameters


Model No.	LED Quantity/pcs	Product Size L*W*H(mm)	Max Run(single feed)(pcs)	Working Temperature	Storage Temperature	
VSL-V-RGBW-0407-24	7	350*25*13	4	-20~+60°C	-20~+70°C	

NOTE:

- 1. Test environment temperature : 25±2°C.
- 2. The above data is typical values. The actual data of each single product may differ from the typical values. The data is subject to change without notice.
- 3. Luminous flux is tested when lighting on with the single color.
- Different color temperature will make luminous flux different.

Profile Drawings


Unit:mm[inch]




NOTE: for detailed drawing, please consult sales rep.



Luminous Intensity Distribution Diagram



Average Illumination




NOTE: The above two igures are tested with the sample VSL-V-RGBW-0407-24, for other data, please consult sales rep.



Reliability Test

Test Sort	Test item	Reference Standard	Test condition	Test result
Environmental	PTC test		TH=-40~60°C, continuous cycle, every 2 hours per times (normal temperature for 15 mitunes, temperature rise and fall for 45 mitunes)	
test	High Temperature Resistance Test		TH=60/80°C, continuous lightened up	PASS
	Room temperature aging test	Internal test standard	TH=25°C, continuous lightened up	
	Luminous flux maintenance test	minous flux maintenance test TH=60°C ,TH=25°C		
Other tests	lens thrust test		>20KGF	
	Wire tensile test		>20KGF	


packing



Put the product into PE bag.




Seal the bag in two ends, and label it.




Separate the product layer by layer with foam



Put the product into carton box.



Seal and label the box.



Use packing belt to pack. Add edge protectors if necessary.

Packaging information

Model No.	Product Size L*W*H(mm)	(Carton Size(mm)		Net Weight(kg)	Gross Weight(kg)	
VSL-V-RGBW-0407-24	350*25*13	390*390*325	150	10.45(1±10%)	11.79(1±10%)	


Note:


- 1. Packing material:PE bags and carton box
- 2. The above quantity and weight are only for the illustrated packaging method. There will be differences in the quantity and weight with other packaging methods.



Installation

1. Connection Diagram






2.Installation Reference

Model No.	Lighting Mode	Surface Material	Width(m)	Depth H(cm)	Color	Illumination (Lux)	Evenness	Watt Density (W/m²)	Density (pcs/2m)	Effect
VSL-V-RGBW -0407-24	Double Side	White non weaving canvas	1.5	12	W	400-630	0.63	8	2*2	OK
					R			8		
					G			8		
					В			8		
					RGB			24		
					RGBW			32		
		White non weaving canvas	2	15	W	300-400	0.75	6	- 2*2	ОК
					R			6		
VSL-V-RGBW					G			6		
-0407-24					В			6		
					RGB			18		
					RGBW			24		


Note

The density is within a light box of 1 square meter. PCS/m indicates the product quantity installed on single side, and PCS/2m indicates the quantity of double-sided installation.







3. Products and Tools












4.Installation Methods and Steps









- 1.Clean the mounting surface
- 2.Determine the mounting distance, fix with the installation clips
- 3. For bare wire connection, please use terminals.
- Treat the thread with insulation, waterproof, and anti-corrosion arrangement as it cannot pull out by hands.
- 4. Check and ensure correct installation, and fix the product with screws ,then power on for self-test.

Note:

- 1. Screw to avoid welding plate, avoiding short circuit
- 2. When fastening the screw, make sure to add plastic gaskets to insulate the screw from the LED panel.





Attentions before installation

Before installation, check that the product parameters are consistent with the requirements (Seeing product specifications or product labels) Load voltage, current, power and power supply should be matched with the product.

Follow the instructions of wiring diagram (first connect the load and then the power supply) to avoid short circuit.

Make sure the correct connection of positive and negative poles between products and power supply. Otherwise, the light will not be on.

Make sure the power cord firmly screwed into the terminal and it should not be pulled out by hands.

The terminal should have insulation, waterproof and anti-corrosive treatment.

Common Faults and Troubleshoot

Quick Guide							
Problems	Reasons	Solutions					
	No electric supply.	Power on					
All LEDs can not light on.	Automatic power protection from the open or short circuit in output of the power supply.	Fix the short circuit problem.					
	Wrong connection of power supply.						
	Some switching mode power supplies are not powered.	Check the power supply					
LEDs can not light on partly.	Power supply line error.	system to fix it.					
	Mistaken wire connection of some of products	Correctly connection					
	Power overloaded.	Replace with more powerful power					
Brightness of LED is inconsistent tor insufficient.	Power supply circuit excessive consumption.	Make sure the working voltage of the product within ±5% of standard voltage, or keep balance by circuit power consumption.					
	Excessive quantities in series connection of the product	Reduce the quantities of the product i series connection to meet requiremen					
	Connection point fault.	Remove bad connection point.					
LED flicker.	Switching power supply failure.	Replace a new power supply.					
	Wrong Installation or use of products	Please follow the instructions					

A Warning

- Do not disassemble or retrofit the light. Do not touch the surface of the light with a sharp object.
- Do not do live-line working during installation, especially for high voltage product.
- Do not use any organic chemical solvents.
- Use neutral glass adhesive to fix this product and it needs to be dried 4 hours in the open environment after operation.
- Treat the ends and the circuit connection points that are not connected to the main line with insulation, waterproof, and anti-corrosion in the installation.
- Use 18AWG (0.75mm² cross-sectional area) or thicker core wire to avoid adverse consequences caused by overheating, if the power cable need to lengthen.
- Make sure the input voltage meets the requirements and lines are connected correctly before lighting on.
- This product is for signage, and do not use as general lighting.
- Series connection within the max run.
- The length of the power cable between the power supply and the led strip should not exceed 2 meters. Otherwise, large circuit loss will lead to inconsistent brightness.
- Installation, maintenance and repair should be operated by a qualified technician.

Statements and Recycling

Statements:

Repair should be operated by a qualified technician, if the external circuit or main line of this product is damaged.

The parameters given in this manual are typical values and for reference only.

All illustrations and drawings in this manual are for reference. This product is subject to change without notice.

, , ,

Recycling

LED lighting products belongs to electronic products, please do recycling treatment according to the relevant WEEE directives.

VIVALYTE B.V.


Tel.:+32 56 42 65 35

Mail:info@vivalyte.com Web:www.vivalyte.com

Add.:Kouterstraat 6, Wevelgem, B-8560, Belgium VAT: BE500611159



Connection Diagram of Controller



Amplifier power supply rated power (W): P Product rated power (W): P(long)
Controller load:M(ncs)

Controller load:M(pcs) Module max run: MAX=50

$$M = \frac{Px0.8}{P_{\text{(long)}}xMAX}$$

For example: the product max run MAX=4pcs, the power supply is 400W , so the controller load is

$$M = \frac{Px0.8}{P_{(long)}xMAX} = \frac{400x0.8}{12x4} \doteq 13(pcs)$$